

BarsIII Professional



Program version: **BMW, BMW_CODING, BMWMINI, BMWSSS**

January 2010

1987-2007 with Manual Selection

SYSTEM	TYPE SYSTEM		YEAR	READ CODE	CLEAR CODE	DATA STREAM	ACTIVATION	CLEAR ADAPTION	SERVICE	EWS SYN.
Drive	DIESEL ENGINE	DDE 2.1 / DDE 2.2	1987-2007	+	+	+	+			
		DDE 3.0 / DDE 5.0	1987-2007	+	+	+			+	Idle speed control
		DDE 4.0	1987-2007	+	+	+	+		+	Idle speed control Compression test Balance test
		DDE 6.0 / DDE 7.0	1987-2007	+	+	+	+			
		M51	1987-2007	+	+					
	GASOLINE ENGINE	DME 1.1	1987-1988	+	+	+	+			
		DME 1.2	1988-1993 (M70 88-	+	+	+	+			

			99/S38 91- 93 M70,1~6 Cyl.)							
		DME 1.2 Right	1991- 1993 (M70,7~12 Cyl.)	+	+	+	+			
		DME 1.3	1988- 1992	+	+	+	+			
		DME 1.7	1992- 1995	+	+	+	+			
		DME 1.7.1 / DME 1.7.1 Right	1994- 1995	+	+	+	+			
		DME 1.7.2	1995	+	+	+	+			
		DME 1.7.3	1992- 1995	+	+	+	+			
		DME 3.1	1991- 1992	+	+	+	+			
		DME 3.3	1993- 1996	+	+	+	+			+
		DME 3.3.1	1993- 1995	+	+	+	+			+
		DME 5.2	10/1995 -6/1999 (M73,1~6 Cyl.)	+	+	+	+	+(M44/M62)		
		DME 5.2 Right	1/1995- 8/2001 (M73,1~12 Cyl.)	+	+	+	+	+(M44/M62)		
		DME	1998-	+	+	+		+		

		5.2.1 / DME 5.2.1 Right	2000 (M73,1~6 Cyl.)							
		NSV 70 M52		+	+	+	+			
		MS 40.0 / MS 40.1	1991- 1995	+	+	+				
		MS 41.0	1995- 1999	+	+	+	+	+		+
		MS 41.1	11/1995 -9/1999	+	+	+	+	+		+
		MS 41.2	4/1996- 8/2000	+	+	+	+	+		
		MS 42	6/1998- 10/2000	+	+	+	+	+	+	+
		MS 43 / MS 45	4/2000- 3/2003	+	+	+	+	+	+	+
		MS S50 / MS S52	7/1999- 8/2003	+	+	+	+	+		
		MS S54	5/2000- 2007	+	+	+		+		
		BMS 43		+	+	+	+	+		+
		BMS 46	1998- 2000	+	+	+	+	+	+	+
		ME 7.2	9/1998- 10/2002	+	+	+	+	+	+	+
		ME 9 N42	11/2001	+	+	+	+	+	+	
		ME 9 N52K (E60/61)		+	+					
		ME 9		+	+	+				

		N52K (E70)								
		ME 9 N62		+	+	+	+	+	+	+
		ME 9 N62TU		+	+	+	+	+	+	+
		ME 9 M54		+	+	+	+			+
		ME 9.2 N46		+	+	+	+	+	+	
		ME 9.2.1 N62	9/2003-9/2005	+	+	+	+	+	+	+
		MSD 80	3/2007-	+	+	+	+			+
		MSD 85		+	+	+	+			
		MSV 70 N52		+	+	+	+		+	
		MSS 65 S85		+	+	+	+			

Drive, EGS/AGS (Transmission) 1987-2007 with Manual Selection

CONTROL SYSTEM	ENGINE MODEL	BODY	TRANSMISSION	READ CODES	CLEAR CODES	DATA STREAM	ACTIVATION	CLEAR ADAPTION
EGS 1.2x	M30, M70	E32	4HP-22/24	+	+		+	
EGS 2.2x	M70, S70	E31, E32	4HP-24	+	+	+	+	+
EGS 4.1x	M42, M43, M44, M50	E34, E36	A4S 270R/310R (THM R1)	+	+	+	+	
EGS 7.10	M50	E34, E36	A5S 310Z (5HP-18)	+	+	+	+	+
EGS 7.11	S50 US	M3	A5S 310Z (5HP-18)	+	+	+	+	+
EGS 7.3	M60B30	E32, E34, E38	A5S 310Z (5HP-18)	+	+	+	+	+

AGS 7.32	M60B30	E32, E34, E38	A5S 310Z (5HP-18)	+	+	+	+	+
AGS 8.32	M51, M52, S52	E36, E38, E39, M3	A5S 310Z (5HP-18)	+	+	+	+	+
EGS 8.34	M43, M44, M52	E36, E38, E39, Z3	A4S 270R (GMPT R1)	+	+	+	+	+
EGS 8.36	M52	E36, E38, E39	A5S 310Z (5HP-18)	+	+	+	+	+
AGS 8.51	M62	E38, E39	A5S 440Z (5HP-24)	+	+	+	+	+
AGS 8.55	M62	E31, E38, E39	A5S 440Z (5HP-24)	+	+	+	+	+
GS 8.60	M52TU	E39, E46		+	+	+	+	+
AGS 8.60.2	M62	E38, E39	A5S 440Z (5HP-24)	+	+	+	+	+
EGS 8.60.4		E36, E38, E39, E46		+	+	+		+
EGS 8.70	M52	E36, E38, E39		+	+	+	+	+
EGS9	M60	E32, E34	A5S 560Z (5HP-30)	+	+	+	+	+
AGS 9.22	M60	E31, E38, E39	A5S 560Z (5HP-30)	+	+	+	+	+
AGS 9.22.1	M62, M73	E31, E38, E39	A5S 560Z (5HP-30)	+	+	+	+	+
GS 20	M43, M52TU	E39, E46	A5S 360R (GM 5)	+	+	+	+	+
SMG	S38, M52, MSS50	M3, M5		+	+	+		
SMG II		M3		+	+	+		+
EGS JECS (Jatco)	M50	E34, E36		+	+	+		
GS19	M54	E60 /E61		+	+	+	+	+
GS19	N62	E63		+	+	+	+	+
GS19	N62	E65/E66		+	+	+		+
GS1904	N62	E53		+	+	+	+	+
GS1911	N46	E90 /E91		+	+		+	+
GS1911.3	N46	E90		+	+	+	+	+
GS1911.3	N54	E71		+	+	+	+	+
6HP19TU	N52K	E60/61		+	+			
6HP19TU	N52K	E70		+	+	+		

Drive, EML (Engine Power Control/Electronic Throttle System) 1988-2000

CONTROL SYSTEM	ENGINE SYSTEM	ENGINE MODEL	BODY	DATA STREAM	READ CODES	CLEAR CODES
EML M70 (12 Cyl)	M1.2, M1.7	M70B50	E32	+	+	+
EML S70 (12 Cyl)	M1.7.1	S70B50	E31, E32	+	+	+
EML M30 (6 Cyl)	M1.3	M30B35	E32	+	+	+
EML IIS M73 (12 Cyl)	M5.2.1	M73B54	E31, E38	+	+	+

Note: EML systems ECU independent up to M73 Engine. Newer EML systems combined in new model Engine control systems (DME/DDE)

Drive Related 1995-2007

SYSTEM	BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
EWS (Electronic Drive-Away Protection)	EWS II – E31, E34, E36, E38, E39 EWS III – E36, E38, E39, E53 EWS III D – Z3	1995-2003 1997-2003 1999-2002	+	+	+	
GR (Cruise Control)	E38, E39, E46, E53			+	+	
GWS (Gear Selection Swith)	E70, E71	2007~		+	+	
	E60/E61	2007~	+	+	+	
EKPS (Electric Fuel Pump)	E60/E61	2007~	+	+	+	+
	E70	2007~		+	+	+
	E71	2007~		+	+	
TOENS (Thermal Oil Level Sensor)	Z3	1996-2002		+	+	
EWA (Anti-theft alarm)	E65,E66		+	+	+	+
VTC 1	E65, E66, E63			+	+	

(Valvetronic 1)						
VTC 2 (Valvetronic 2)	E65, E66, E63			+	+	
QMVH (Lateral-moment distribution, rear axle)	E71		+	+	+	+
CAS (Car Access System)	E 87, E90, E91, E60, E61, E63, E65, E66, E70, E71	1995-2007		+	+	
	E60/E61	2007~	+	+	+	+
	E70	2007~		+	+	+

CHASSIS, ABS/ASC/DSC 1988-2007 with Manual Selection

SYSTEM MAKE	CONTROL SYSTEM	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
BOSCH	ABS MK	+	+	+	
TEVES	ABS MK IV/3	+	+	+	+
TEVES	ABS MK IV/G	+	+	+	+
TEVES	ABS MK IV/G1	+	+	+	+
TEVES	ABS MK 20-I/ERL	+	+	+	+
BOSCH	ABS 5	+	+	+	+
TEVES	ABS/ASC	+	+	+	+
BOSCH	ABS/ASC	+	+	+	+
TEVES	ABS/ASC for 4 Cyl	+	+	+	+
TEVES	ABS/ASC MK IV/3	+	+	+	+
TEVES	ABS/ASC 20-I/ERL	+	+	+	
BOSCH	ABS/ASC 5 M51/M60/M62	+	+	+	+
TEVES	ABS/ASC ITT Auto ERL	+	+	+	
BOSCH	ABS/ASC 5.7	+	+	+	+
BOSCH	ABS/DSC 2	+	+	+	+
BOSCH	ABS/DSC 3 M62/M73	+	+	+	+

BOSCH	ABS/DSC 5.0	+	+	+	
BOSCH	ABS/DSC 5.7	+	+	+	+
BOSCH	ABS/DSC E46	+	+	+	
BOSCH	ABS/DSC E65/E66	+	+	+	
BOSCH	ABS/DSC E60/E61 (~2007)	+	+	+	+
BOSCH	DSC E90/E91	+	+	+	+
TEVES	ABS/ASC M44	+	+	+	+
TEVES	DSC MK60	+	+	+	+
BOSCH	DSC 7.0 E70/E71	+	+	+	+
BOSCH	DSC 8	+	+	+	+
BOSCH	DSC 8PLUS	+	+	+	+

CHASSIS RELATED 1988-2007

SYSTEM	BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
EDC (Electronic Damper Control)	E31,E32,E38	1988-2001		+	+	
EDC (Electronic Damper Control)	E60/E61 (~2007)		+	+	+	+
EDCSHL (Damper satellite, rear left)	E70, E71		+	+	+	+
EDCSHR (Damper satellite, rear right)	E70, E71		+	+	+	+
EDCSVL (Damper satellite, front left)	E70, E71		+	+	+	+
EDCSVR (Damper satellite, front right)	E70, E71		+	+	+	+
EHC (Electronic Height Control)	E39 (Wagon 99~), E53, E65/E66, E71	1999-2004	+	+	+	+
ICM (Integrated Chassis Management)	E71		+	+	+	+
LWS/LEW (Steering Angle Sensor)	Z3, E38, E39, E46, E52, E53	1996-2004		+	+	
RDC/RDW (Tire Pressure Control)	E38, E39, E46, E52, E53, E71	1996-2004	+	+	+	
VDM (Vertical Dynamics Management)	E71		+	+	+	+
VTG (Transfer case)	E53, E71		+	+	+	+

ELV (Electrical Steering Column Lock)	Z3, E38, E39, E46, E52, E53	1996-2004		+	+	
AHK (Active Real Axle Kinematics)	E32, E34	1988-1994		+	+	
CIM (Chassis integration module)	E65/E66		+	+	+	+
AFS (Active Front Steering)	E60/E61 (~2007)		+	+	+	
EMF (Electro-Mechanical parking brake)	E65/E66, E71		+	+	+	+
AL (Active Steering)	E63, E71		+	+	+	
ARS (Dynamic Drive 2)	E63, E71		+	+	+	+

BODY, SRS (AIR BAG) 1988-2007

BODY TYPE	AIR BAGS	CONTROL SYSTEM TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES
E30,E31,E32, E34	Drivers Air bag	5WK4 027	1988-1991		+	+
E31,E32, E34, E36	Drivers Air bag	5WK4 060	1991-1993		+	+
E31,E32, E34, E36, E38	1 or 2 Air bags	ZAE, BAE	1993-1995		+	+
E31.E36,E38,E39,Z3	4 or 8 Air bags	ZAE2, MRS, MRS2	1995-1999		+	+
E38, E39, E46, Z3	6 or 10 Air bags	MRS3	1999-2001		+	+
E38,E39,E46,E53	6 or 10 Air bags	MRS4	2001-2003		+	+
E87,E90/E91	1 or 2 Air bags	MRS5	2004-2006	+	+	+
E60/E61(~2007),E85	6 or 10 Air bags	SFZ, SBSL, SBSR	2002-2004	+	+	+
E65/E66,E85	8 or 10 Air bags	SASL, SASR, SBSL, SBSR, SSFA, SSBF, SSH, SFZ, STVL, STVR	2002-2004	+	+	+
E63, E70, E71, E85/E86 (9/2005~)	6 or 10 Air bags	ACSM			+	+
E60/E61(2007~)				+	+	+

BODY, INSTRUMENT CLUSTER 1987-2007

BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
E31, E32, E34, E36, E38, E39, E46, E52, E53, E63,	1987-2007		+	+	

E65/E66, E85, E70, E71, E87, E90, Z3					
E60/61	2007~	+	+	+	+

SERVICE INTERVAL RESET (ANALOG)					
BODY TYPE	MODEL YEAR	OIL MILEAGE	INSPECTION		
E30 (3 series)	1988-1990	+	+		
E36 (3 series)	1991-1998	+	+		
E34 (5 series)	1988-1995	+	+		
E32 (7 series)	1987-1994	+	+		
E31 (8 series)	1990-1998	+	+		
SERVICE INTERVAL RESET (DIGITAL)					
BODY	MODEL YEAR	OIL MILEAGE	SERVICE TIME	SERVICE DISTANCE	ATF OIL
E36 (3 series)	1995-1998	+	+	+	+ (up to 1995)(no ATF oil Reset function from Kombi E36)
E36/7 (Z3)	1996-2002	+	+	+	
E46 (3series)	1999-2004	+	+	+	
E34 (5 series)	1988-1995	+	+	+	+
E39 (5 series)	1995-2003	+	+	+	
E38 (7 series)	1994-2002	+	+	+	
E52 (Z8)	2001-2003	+	+	+	
E53 (X5)	2000-2004	+	+	+	

SERVICE RESET			
CONTROL SYSTEM	BODY TYPE	CONTROL FUNCTION	ADAPTATION
CBS RESET 1	E60/E61 ~2007	Time Reset Service	+
	E63	Engine Oil	+
	E65/E66	Microfilter	+
	E70 (Microfilter not included)	Front brakes	+
	E87 (TIME RESET not included)	Rear Brakes	+

	E90/E91 (TIME RESET not included)	Vehicle Check	+
CBS RESET 2	E60/E61~2007	Spark Plugs	+
	E63	Brake Fluid	+
	E65/ E66	Coolant	+
	E70 (Spark Plugs, Coolant not included)	Vehicle Inspection	+
	E87 (COOLANT RESET not included)	Exhaust Emission Inspection	+
	E90 /E91(COOLANT RESET not included)		

BODY, ZKE (Central Body Electronics) 1988-2006

CONTROL SYSTEM	BODY TYPE	MODEL YEAR	CONTROL FUNCTION ECUs		DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
ZKE 1	E32	1987-1994	Wiper and washer control		+	+	+	+
	E34	1988-1995	Contact pressure control		+	+	+	+
			Head-light cleaning system		+	+	+	+
			Central locking(ZV)		+	+	+	+
			Door heating		+	+	+	+
			Power windows (FH)		+	+	+	+
			Sliding/tilting sunroof (SHD)		+	+	+	+
			Electronic fuse		+	+	+	+
ZKE 2	E31	1990-1998	Interior lights			+	+	
			Wiper and washer control			+	+	
			ADV			+	+	
			SRA			+	+	
			Head-light cleaning system			+	+	
			Central locking(ZV)			+	+	
			Power windows (FH)			+	+	
			Sliding/tilting sunroof (SHD)			+	+	
			Door lock heating (TSH)			+	+	
ZKE 3	E38	1994-2002	Base module (GM)	Door contact	+	+	+	+
	E39	1995-2003		Central locking	+	+	+	+

	E53	2000-2006			Power windows	+	+	+	+
					Wiper	+	+	+	+
					Anti-theft	+	+	+	+
					Interior lights	+	+	+	+
			Driver door (FT)			+	+	+	+
			Driver memory (SM/LSM)			+	+	+	+
			Passenger memory (SM BF)			+	+	+	+
			Passenger memory rear (SM SFB)			+	+	+	+
ZKE 4	E36 Z3	5/1994-1999 5/1997-2002	Central locking			+	+	+	+
			Power windows			+	+	+	+
			Interior lights			+	+	+	+
ZKE 5	E46 E52	1999-2004 2000-2003	PM	Sunroof		+	+	+	+
				Driver seat memory		+	+	+	+
				Passenger seat memory		+	+	+	+
				Switch block		+	+	+	+
			SA	Wiper		+	+	+	+
				Headlight cleaning		+	+	+	+
				Door locking		+	+	+	+
				Rear view mirror		+	+	+	+
				SCA truck lid		+	+	+	+
				Central Locking		+	+	+	+
				Power window		+	+	+	+
			Anti-theft system (DWA)				+	+	+

BODY RELATED 1995-2007

SYSTEM	BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
LM/LCM/LSZ (Light check module)	LM/LCM – E38, E39, E52, E53, E65/E66, E60/E61 LSZ – E46 LM2 – E63	9/1995-2007	+ E60/E61(2007~)	+	+	+ E60/E61(2007~)
LRA (Headlight vertical aim control)	E38,E39,E53		+	+	+	+
FLA (High Beam Assist)	E63,E71			+	+	+
SZM/SZL (Center Console switch Center)	E38, E39, E46, E60,E61, E63 SZL: E65, E66, E63	1995-2006	+	+	+	+
XENON_L (Xenon head light, Left)	E38, E39, E46, E53	1999-2006	+	+	+	
XENON_R (Xenon head light, Right)	E38, E39, E46, E53	1999-2006	+	+	+	
PDC (Park Distance Control)	E36, Z3, E38, E39, E46, E65, E66,E60, E61, E70,E71 E90, E91, E63		+ E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
CVM (Convertible Top)	E36, Z3, E46, E85		+	+	+	
AIC/RLS (Rain Sensor/Rain and Light Sensor)	E38, E39, E46, E52, E53, E65, E66, E60, E61, E71,E87, E90, E91, E63		+	+	+	
MFL (Multi-functional Steering Wheel)	E38, E39, E46, E53			+	+	
SHD (Sunroof)	E38, E39, E46, E53, E60, E61, E70, E63		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
SM (Seat Memory)	E38, E39, E46, E53		+	+	+	+
CCM (Check Control Module)	E38, E39, E46			+	+	
BSM/SMB (Seat Memory,	E38, E39, E46, E53			+	+	

Passenger Side)						
FBZV (Remote Control for Central Lock)	E38, E39, E46, E53			+	+	
HKM (Trunk Lid Module)	E38, E39, E46, E53			+	+	
SBE2 (Seat Occupation Detection)	E38, E39, E46, E53			+	+	
SPMBT (Mirror Memory, Passenger Side)	E38, E39, E46, E53			+	+	
SPMFT (Mirror Memory, Driver Side)	E38, E39, E46, E53			+	+	
ZUHEIZ/STH (Additional Heater, Park Heating)				+	+	
TMFAT (Driver door)	E65/E66, E60/E61(~2007)		+	+	+	+
TMBFT (Driver side rear door)	E65/E66, E60/E61(~2007)		+	+	+	+
TMFAH (Driver side rear door)	E65,E66		+	+	+	
TMBFH (Passenger side rear door)	E65.E66		+	+	+	
MPM (Micro Power Control)	E60/E61(~2007)		+	+	+	+
KBM (Body Basic Module)	E60,E61,E70, E63		+	+	+	+
			E70,E60/E61(2007~)			E70,E60/E61(2007~)
FRM (Foot Well Module)	E87, E90, E91		+	+	+	+
FZD Function Centre Roof)	E87, E90, E91		+	+	+	+
SMFA Seat Module, Driver)	E60,E61,E70, E71,E87, E90, E91		+	+	+	+
			E70,E60/E61(2007~)			E70,E60/E61(2007~)
SMBF (Seat Module, Passenger)	E60/E61 (~2007)		+	+	+	+
PM (Power Module)	E65,E66		+	+	+	+
HKL (Rear-lid lift)	E65,E66,E71		+	+	+	+
AHL (Active Head Light)	E60/E61 (~2007)		+	+	+	+
KGM (Body Gateway Module)	E63, E70, E60/E61 (2007~)		+	+	+	+
			E70,E60/E61(2007~)			E70,E60/E61(2007~)

SINE (Siren and tilt Sensor)	E60/E61 (~2007)		+	+	+	
ALBFA (Active Backrest Width, Driver)	E60/E61 (~2007)		+	+	+	
ALBBF (Active Backrest Width, front passenger)	E60/E61 (~2007)		+	+	+	

INFORMATION AND COMMUNICATION

SYSTEM	BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
BIT (Basis Interface telephone)	E38, E39, E46, E52, E53	1997-2004		+	+	
BMBT (On-board Monitor)	E38,E39, E46, E53	1997-2004		+	+	
DSP (DSP Booster Module)	E38,E39, E46, E53	1995-2004		+	+	
FOND_ZIS/FID (Rear Multi-information Display)	E38	1998-2001		+	+	
ZIS/MID (Multi-information Display)	E38,E39, E46, E53	1995-2004		+	+	
IRIS (Integrated Radio Information System)	E38,E39, E46, E53	1998-2004		+	+	
NAV (Navigation System)	E38,E39, E46, E52, E53, E60/E61(~2007)	1997-2004		+	+	
NAV JAP (Japanese Version Navigation System)	E38,E39, E46, E53, E60/E61(~2007)	1998-2004		+	+	+
RAD (Radio)	E38,E39, E46, E52, E53	1995-2004	+	+	+	+
RAD2 (Radio)	E87, E90, E91	2004-2006	+	+	+	+
VIDEO_GT (Video Module Graphics Part)	E38,E39, E46, E53	1998-2004		+	+	
VIDEO_TV/VID (Video Module TV part)	E38,E39, E46, E53	1998-2004		+	+	
SIM (Safety and Information module)	E60/E61(~2007), E65,E66	2002-2004	+	+	+	+
ASK (Audio System)	E65,E66	2002-2004	+	+	+	+
CD (Control Display)	E65,E66	2002-2004		+	+	+

CDGW (Control display GW)	E65,E66	2002-2004	+	+	+	+
CDC (CD changer)	E65,E66, E63, E60,E61,E70,E71	2002-2004		+	+	+ E70,E60/E61(2007~)
DVDC (DVD changer)	E65,E66	2002-2004		+	+	
CA (Comfort Access)	E63,E71	2002-2004	+	+	+	
CCCA (CCC-A Applications)	E60/E61(~2007), E71		+	+	+	+
CCCANT (CCC-ANT Antenna tunner)	E60,E61,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
CCCASK (CCC-ASK Audio system controller)	E60,E61,E70,E71		+ E70,E60/E61(2007~)	+	+	+
CCCBO (CCC-BO User Interface)	E60,E61,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
CCCBW (CCC-GW Gateway)	E60,E61,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
CID (Central Information)	E60,E61, E63,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
SGMSIM (Safety and Gateway Module (SIM))	E60,E61(~2007)		+	+	+	+
SGMZGM (Safety and Gateway Module (ZGM))	E60,E61(~2007)			+	+	
TCU (Telematic Control)	E60,E61,E70,E71			+	+	+ E70,E60/E61(2007~)
CON (CON control)	E60,E61, E63,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
VM (Video Module)	E60,E61		+	+	+	+
MASKNAV (Navigation System)	E60,E61		+	+	+	
MASKBO (Navigation System User Interface)	E60,E61, E63,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
MASKGW (Navigation System Gateway)	E60,E61, E63,E70,E71		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
ULF (Hands Free Utility)	E60,E61, E63, E70, E90		+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
JBE (Junction Box Electronics)	E71,E87, E90, E91		+	+	+	+
BYTEF (Byte Flight)	E60,E61			+	+	
HUD (Head-Up Display)	E60,E61, E63,E71		+	+	+	+

AMP (Amplifier)	E60,E61, E63		+	+	+	+
AMPH (Hi-Fi amplifier)	E71		+	+	+	+
AMPT (Top Hi-Fi amplifier)	E71		+	+	+	+
SDARS (Satellite tuner)	E71		+	+	+	+
FRM2 (Foot well module 2)	E71		+	+	+	+
RFK (Reversing camera)	E71		+	+	+	+
ULF_SBOX (Interfase box)	E71		+	+	+	+
VSW (Video switch)	E71		+	+	+	+

AIR CONDITIONING

SYSTEM	BODY TYPE	MODEL YEAR	DATA STREAM	READ CODES	CLEAR CODES	ACTIVATION
IHKR (Automatic Heating and A/C)	3 Series – E36, Z3, E46, E90 5 Series – E34, E39, E60,E61 8 Series – E31 X5 -E53	1987-2006	+	+	+	+
IHKA (Regulated Heating and A/C)	1 Series – E87 3 Series – E36, E46 5 Series – E34, E39, E60,E61 6 Series – E63 7 Series – E32, E38, E65,E66 8 Series – E31 X5 -E53, E70,E71	1987-2006	+ E70,E60/E61(2007~)	+	+	+ E70,E60/E61(2007~)
	X3 -E83 Z4 -E85	2003-2004		+	+	
IHKS (Standard Heating and A/C)	E36/5 (ti), Z3, Z8	1991-2003	+	+	+	
FKA (Rear heater/air conditioning)	E65,E66, E71		+	+	+	+
FGB (Rear Compartment Blower)	E38	1995-2001		+	+	

CODING AND PROGRAMMING

SYSTEM	BODY TYPE	FUNCTIONS DESCRIPTION
KOMBI	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Recoding, Emergency Recovery
LEW	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Recoding
AIRBAG	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Recoding
IHKA/IHKR	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Recoding
LCM	5 series – E39 / 7 series – E38 / X series – E53	Recoding
LSZ	3 series – E46	Recoding
ASC	5 series – E39	Recoding
DSC	7 series – E38 / 3 series – E46 / X series – E53	Recoding
ZKE	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Recoding
RETROFIT XENON LIGHT	5 series – E39 / 7 series – E38 / 3 series – E46 / X series – E53	Retrofit

KEY MEMORY

PROGRAMMING	BODY TYPE	FUNCTIONS	DESCRIPTION
KEY MEMORY (KEY1, KEY2) after 1999/09	5 series – E39 7 series – E38	Automatic locking after starting off	The vehicle is automatically locked after pulling away. Doors can be unlocked at any time from the inside.
		Selective central locking system	The first time the button on the key is pressed, only the driver's door is unlocked. If it is pressed a second time, the whole car is opened. This function is only effective when the remote control is used.
KEY MEMORY (KEY1- KEY4) after 1999/09	3 series – E46 X series – E53	Automatic locking after starting off	The vehicle is automatically locked after pulling away. Doors can be unlocked at any time from the inside.
		Selective central locking system	The first time the button on the key is pressed, only the driver's door is unlocked. If it is pressed a second time, the whole car is opened. This function is only effective when the remote control is used.
KEY INFORMATION	E38 / E39/ E46 / E 53	Last-used key	Show the last-used key with remote control.

CAR MEMORY after 1999/09

PROGRAMMING	BODY TYPE	FUNCTIONS	DESCRIPTION
CENTRAL LOCKING SYSTEM	5 series – E39	RC interior light	The interior lighting is switched on if the car is locked and the lock button on the key is pressed.
	7 series – E38		
	3 series – E46	Lock again 2 min	The vehicle will automatically lock again approx. 2 minutes after a single inadvertent unlocking (when no door or hatch was opened afterwards)
	X series – E53	Automatic locking after starting off	The vehicle is automatically locked after pulling away. Doors can be unlocked at any time from the inside.
POWER WINDOW / SLIDING / TILT SUNROOF	5 series – E39	Switch off at open/close door	When “Open door” is selected, the power windows are deactivated if terminal R is “off” and the front door is open.
	7 series – E38		
	3 series – E46	One-touch open driver’s window	Open driver’s window in one-touch.
	X series – E53	One-touch close driver’s window	Close driver’s window in one-touch.
		One-touch open passenger’s window	Open passenger’s window in one-touch.
		One-touch close passenger’s window	Close passenger’s window in one-touch.
		One-touch open rear’s window	Open rear’s window in one-touch.
		One-touch close rear’s window	Close rear’s window in one-touch.
		One-touch open sunroof	Open sunroof in one-touch.

		One-touch close sunroof	Close sunroof in one-touch.
		Convenient Locking RC	Windows and sliding/tilt sunroof can be closed by pressing the lock button on the key with remote control apply constant pressure to the "Lock" button.
		Convenient Opening RC	Windows and sliding/tilt sunroof can be opened by pressing the unlock button on the key with remote control apply constant pressure to the "Unlock" button.
LIGHTING	5 series – E39 7 series – E38 X series – E53	Soft on/off	Dimmed interior lighting is switched on and off.
		Daytime driving	The daytime driving lights are switched on as soon as the ignition is switched on and the light switch is turned to "position 2".
		Home lights	If terminal R is "off", the driving lights are switched on for the period of time selected when the headlight flasher is pulled. The following settings are possible: not active, 40s, 90s, 150s and 240s.
	3 series – E46	On during unlock	The interior lighting is switched on when manual unlocking is used.
		On at terminal R off light on beforehand	The interior lighting is only switched on when terminal R is "off" after driving with lights on.
		Soft on/off	Dimmed interior lighting is switched on and off.

		Daytime driving	The daytime driving lights are switched on as soon as the ignition is switched on and the light switch is turned to "position 2".
		Home lights	If terminal R is "off", the driving lights are switched on for the period of time selected when the headlight flasher is pulled. The following settings are possible: not active, 40s, 90s, 150s and 240s.
WINDSCREEN WIPERS	5 series – E39 X series – E53	Switch back when stationary	The system switches from speed 1 to intermittent operation or from speed 2 to speed 1 when the vehicle is stationary.
DISPLAY / LANGUAGE (without on-board monitor)	5 series – E39 7 series – E38 3 series – E46 X series – E53	Consumpt	Fuel consumption: litres/100 km, mpg (UK), mpg (US), km/ liter
		Distance	Km/miles
		Time	12h/24h
		Temperature	Degrees C / Degrees F
		Language	The display texts can be displayed in the given languages. English, French, Italian, Spanish, German

5 series – E65 Coding and Programming

CKM (KEY MEMORY AND CAR MEMORY)

FUNCTIONS	DESCRIPTION
Lighting	Daytime driving lights
Power Windows / SHD	Windows one-touch open / close
Central Locking	Lock after unlock / Autolock after driver off / Selective locking
Anti-theft	Arming / Disarming

7 series – E65 Coding and Programming

CKM (KEY MEMORY AND CAR MEMORY)

FUNCTIONS	DESCRIPTION
Lighting	Daytime driving lights
Power Windows / SHD	Windows one-touch open / close
Central Locking	Lock after unlock / Autolock after driver off / Selective locking
Anti-theft	Arming / Disarming
Mirror / Seat	Automatic Adjustment
Air Condition	Turn on air condition after ignition on.
Parking Aid	The volume adjustment

FOR MINI R50, R52, R53

SYSTEM		READ CODE	CLEAR CODE	DATA STREAM	ACTIVATION	ADAPTATION
POWER TRAIN	EMS2	+	+	+	+	
	EWS3	+	+			
CHASSIS	DSC MK60	+	+	+	+	
BODY	KOMBI KR50	+	+		+	Service Reset: 1.Oil Service 2.Time Inspection 3.Distance Inspection
	KOM2	ID only				
	EHPS(Electro-hydraulic Steering Assist)	+	+			
	Steering-angle sensor	+	+			
	PDC	+	+			
	ZKE	+	+	+	+	
	MRS4	+	+			
COMMUNICATION INFORMATION	DSP-booster	ID only				
	Radio	+	+			
AIR CONDITION	IHKA/IHKR (AC/heater)	+	+	+	+	